



Breakdown Sheet
Heavy Duty – Straight Handle
Model 250202 Needle Scaler Round Nose Instructions & Parts



Item	Part Number	Description	Item	Part Number	Description
1	76100	Straight Handle	11	73202	Throttle Stem
2	240202	Barrel	12	73500	Small Rubber Seal
3	240600	Piston	13	73700	Trigger Washer
4	240301	Front Valve Block	14	73800	Elastic Stop Nut
5	241800	Wafer	15	73300	Trigger Body
6	240501	Back Valve Block	16	73400	Larger Rubber Seal
7	240700	Pin (2 req.)	17	73900	Trigger Lever Pin/Washer
8	153600	Socket Set Screw	18	92600	Trigger Depressor Lever
10	4700	Beehive Spring	19	76000	Inlet Bushing

Round Nose Attachment & Instructions

Item	Part Number	Description
1	250002	Housing
2	250004	Spring
3	250024	Needles (16 req.)
4	250008	Cushion (2 req.)
5	250003	Needle Holder
6	250010	Driver
7	250007	Retainer
8	250016	Housing Strap
9	250012	Strap Nut
10	250013	Strap Screw
11	250006	Barrel Spring





Disassembly

1. Remove the retainer (No. 250007) by prying it out with a screwdriver.
 - a. The retainer can be pried back in with a screwdriver when re-assembling.
2. Once the retainer is removed, all other parts will drop out.

Model 250200 Needle Scaler Vacuum Adapter Instructions & Parts

(For Models 240008, 250101, 250102, 250201, & 250202)



Parts Provided

Part Number	Description
250005	Clamp Vacuum Housing
95528	3/4" Flexible Hose 1 1/4" Cuff Adapter Releasable Cable Tie